

```
1 from google.colab import drive
2 drive.mount('/content/drive')
```

↔ Mounted at /content/drive

```
1 import csv
2 import numpy as np
3 import pandas as pd
4 import math
5 import time
6
```

```
1 import matplotlib.pyplot as plt
2 from mpl_toolkits.mplot3d import Axes3D
3 from mpl_toolkits.mplot3d.art3d import Poly3DCollection
4
```

```
1 import os
2 import torch
3 import numpy as np
4 import pickle
5 import logging
6 import random
7 from tqdm import tqdm
8 #from torch_geometric.data import Dataset
```

## ✓ Read data

```
1 import sys
2 sys.path.append('/content/drive/MyDrive/action/data/processed/mmr_kp')
```

```
1 filename = "/content/drive/MyDrive/action/data/processed/mmr_kp/data.pkl"
```

```
1 import os
2 import numpy as np
3 import pandas as pd
4 import pickle
5 import matplotlib.pyplot as plt
6 from mpl_toolkits.mplot3d import Axes3D
7
8 class MMRDataAnalyzer:
9     def __init__(self, data_path):
10         """Initialize analyzer with data path"""
```

```

11     self.data_path = data_path
12     self.data = self.load_processed_data()
13     self.train_data = self.data['train']
14     self.full_df = None
15
16     def load_processed_data(self):
17         """Load processed MMR data from pickle file"""
18         with open(self.data_path, 'rb') as f:
19             return pickle.load(f)
20
21     def get_frame_data(self, data_point):
22         """Convert a single data point to DataFrame"""
23         x = data_point['new_x']
24         df = pd.DataFrame({
25             'frame_num': np.zeros(len(x)),
26             'x': x[:, 0],
27             'y': x[:, 1],
28             'z': x[:, 2]
29         })
30         if 'cluster_labels' in data_point:
31             df['cluster'] = data_point['cluster_labels']
32         return df
33
34     def analyze_dataset(self):
35         """Analyze entire dataset"""
36         all_points = []
37         all_frames = []
38         frame_count = 0
39
40         for data_point in self.train_data:
41             x = data_point['new_x']
42             num_points = len(x)
43             all_points.append(x)
44             all_frames.extend([frame_count] * num_points)
45             frame_count += 1
46
47         all_points = np.concatenate(all_points, axis=0)
48         self.full_df = pd.DataFrame({
49             'frame_num': all_frames,
50             'x': all_points[:, 0],
51             'y': all_points[:, 1],
52             'z': all_points[:, 2]
53         })
54         return self.full_df
55
56     def visualize_frame(self, frame_idx=0, title="Point Cloud Visualization")
57         """Visualize a single frame of point cloud data"""
58         data_point = self.train_data[frame_idx]
59         x = data_point['new_x']
60
61         fig = plt.figure(figsize=(12, 8))

```

```

62     ax = fig.add_subplot(111, projection='3d')
63     scatter = ax.scatter(x[:, 0], x[:, 1], x[:, 2],
64                          c=x[:, 2],
65                          cmap='viridis',
66                          marker='o',
67                          s=50)
68
69     ax.set_xlabel('X')
70     ax.set_ylabel('Y')
71     ax.set_zlabel('Z')
72     ax.set_title(title)
73     plt.colorbar(scatter, label='Z coordinate')
74     plt.show()
75
76     def analyze_by_action(self):
77         """Analyze data grouped by action labels"""
78         if 'y' not in self.train_data[0]:
79             return None
80
81         action_data = {}
82         action_labels = [d['y'] for d in self.train_data]
83
84         for data_point, action in zip(self.train_data, action_labels):
85             if action not in action_data:
86                 action_data[action] = []
87             action_data[action].append(data_point['new_x'])
88
89         stats = {}
90         for action, points in action_data.items():
91             points = np.concatenate(points, axis=0)
92             df = pd.DataFrame({
93                 'x': points[:, 0],
94                 'y': points[:, 1],
95                 'z': points[:, 2]
96             })
97             stats[action] = df.describe()
98         return stats
99
100     def plot_coordinate_distributions(self):
101         """Plot distributions of x, y, z coordinates"""
102         if self.full_df is None:
103             self.analyze_dataset()
104
105         fig, axes = plt.subplots(1, 3, figsize=(15, 5))
106
107         for i, coord in enumerate(['x', 'y', 'z']):
108             axes[i].hist(self.full_df[coord], bins=50)
109             axes[i].set_title(f'{coord.upper()} Distribution')
110             axes[i].set_xlabel(f'{coord.upper()} Coordinate')
111             axes[i].set_ylabel('Frequency')
112

```

```

113     plt.tight_layout()
114     plt.show()
115
116     def print_detailed_statistics(self):
117         """Print detailed statistics for each coordinate"""
118         if self.full_df is None:
119             self.analyze_dataset()
120
121         # Percentile analysis
122         for coord in ['x', 'y', 'z']:
123             print(f"\nDetailed {coord.upper()} coordinate analysis:")
124             percentiles = [0, 1, 5, 25, 50, 75, 95, 99, 100]
125             for p in percentiles:
126                 value = np.percentile(self.full_df[coord], p)
127                 print(f"{p}th percentile: {value:.6f}")
128
129             print(f"Mean: {self.full_df[coord].mean():.6f}")
130             print(f"Std: {self.full_df[coord].std():.6f}")
131             print(f"Skewness: {self.full_df[coord].skew():.6f}")
132             print(f"Kurtosis: {self.full_df[coord].kurtosis():.6f}")
133
134         # Non-zero analysis
135         print("\nAnalysis of non-zero points:")
136         for coord in ['x', 'y', 'z']:
137             non_zero = self.full_df[self.full_df[coord] != 0][coord]
138             print(f"\n{coord.upper()} coordinate (non-zero):")
139             print(f"Count: {len(non_zero)}")
140             print(f"Mean: {non_zero.mean():.6f}")
141             print(f"Std: {non_zero.std():.6f}")
142             print(f"Min: {non_zero.min():.6f}")
143             print(f"Max: {non_zero.max():.6f}")
144
145     def analyze_points_per_frame(self):
146         """Analyze and visualize points per frame distribution"""
147         points_per_frame = [len(d['new_x']) for d in self.train_data]
148
149         print("\nPoints per frame:")
150         print(f"Mean: {np.mean(points_per_frame):.2f}")
151         print(f"Std: {np.std(points_per_frame):.2f}")
152         print(f"Min: {np.min(points_per_frame)}")
153         print(f"Max: {np.max(points_per_frame)}")
154
155         plt.figure(figsize=(10, 5))
156         plt.hist(points_per_frame, bins=50)
157         plt.title('Distribution of Points per Frame')
158         plt.xlabel('Number of Points')
159         plt.ylabel('Frequency')
160         plt.show()
161
162     def main():
163         # Initialize analyzer

```

```

164 data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
165 analyzer = MMRDataAnalyzer(data_path)
166
167 # Run analyses
168 print("\nAnalyzing training data...")
169
170 # Single frame analysis
171 print("\nSingle Frame Analysis:")
172 frame_df = analyzer.get_frame_data(analyzer.train_data[0])
173 print("\nFrame Statistics:")
174 print(frame_df.describe())
175
176 # Visualize first frame
177 print("\nVisualizing first frame...")
178 analyzer.visualize_frame(0)
179
180 # Full dataset analysis
181 print("\nFull Dataset Analysis:")
182 full_df = analyzer.analyze_dataset()
183 print("\nDataset Statistics:")
184 print(full_df.describe())
185
186 # Plot distributions
187 analyzer.plot_coordinate_distributions()
188
189 # Action analysis
190 action_stats = analyzer.analyze_by_action()
191 if action_stats:
192     print("\nAnalysis by Action:")
193     for action, stats in action_stats.items():
194         print(f"\nAction {action} Statistics:")
195         print(stats)
196
197 # Points per frame analysis
198 analyzer.analyze_points_per_frame()
199
200 # Detailed statistics
201 analyzer.print_detailed_statistics()
202
203 if __name__ == "__main__":
204     main()

```



Analyzing training data...

Single Frame Analysis:


Frame Statistics:

	frame_num	x	y	z
count	110.0	110.000000	110.000000	110.000000
mean	0.0	0.047783	0.536345	-0.038962
std	0.0	0.349468	0.975685	0.212701
min	0.0	-1.158141	0.000000	-0.868396

min	0.0	-1.130141	0.000000	-0.000000
25%	0.0	0.000000	0.000000	0.000000
50%	0.0	0.000000	0.000000	0.000000
75%	0.0	0.000000	0.577146	0.000000
max	0.0	1.202685	3.890844	0.614703

Visualizing first frame...

Point Cloud Visualization



Full Dataset Analysis:

Dataset Statistics:

	frame_num	x	y	z
count	1.873696e+07	1.873696e+07	1.873696e+07	1.873696e+07
mean	8.516750e+04	7.687180e-02	5.204076e-01	-5.673060e-02
std	4.917177e+04	3.291378e-01	9.468305e-01	2.585428e-01
min	0.000000e+00	-1.399950e+00	0.000000e+00	-1.399992e+00
25%	4.258375e+04	0.000000e+00	0.000000e+00	0.000000e+00
50%	8.516750e+04	0.000000e+00	0.000000e+00	0.000000e+00

## ✓ Small tool functions

```

1 import numpy as np
2 from sklearn.preprocessing import MinMaxScaler
3

```

```

4 class MMRUtils:
5     @staticmethod
6     def normalize(x, x_min=None, x_max=None):
7         """Normalize data to [0,1] range"""
8         if x_min is None:
9             x_min = np.min(x)
10        if x_max is None:
11            x_max = np.max(x)
12        return (x - x_min) / (x_max - x_min)
13
14    @staticmethod
15    def normalize_points(points):
16        """Normalize point cloud data"""
17        normalized = np.zeros_like(points)
18        for i in range(points.shape[1]):
19            normalized[:, i] = MMRUtils.normalize(points[:, i])
20        return normalized
21
22    @staticmethod
23    def weight_by_intensity(data_point):
24        """Convert intensity values to weights in [0,1] range"""
25        if 'intensity' in data_point:
26            intensities = data_point['intensity']
27            return MinMaxScaler().fit_transform(
28                np.asarray(intensities).reshape(-1,1)).reshape(1,-1)[0]
29        return None
30
31    @staticmethod
32    def to_vertical(array):
33        """Convert array to vertical format"""
34        return array.reshape(-1, 1)
35
36    @staticmethod
37    def to_horizontal(array):
38        """Convert array to horizontal format"""
39        return array.reshape(1, -1)
40
41    @staticmethod
42    def vector_angle(vec1, vec2):
43        """Calculate normalized angle between two vectors"""
44        return np.abs(np.dot(vec1, vec2)) / (np.linalg.norm(vec1) * np.linalg
45
46    @staticmethod
47    def cartesian_to_spherical(points):
48        """Convert cartesian coordinates to spherical
49        Args:
50            points: Array of shape (N, 3) containing [x, y, z] coordinates
51        Returns:
52            Array of shape (N, 3) containing [r, theta, phi] coordinates
53        """
54        x, y, z = points[:, 0], points[:, 1], points[:, 2]

```

```

55     r = np.sqrt(x**2 + y**2 + z**2)
56     theta = np.arctan2(y, x)
57     theta[theta < 0] += 2 * np.pi
58     phi = np.arctan2(np.sqrt(x**2 + y**2), z)
59     return np.stack([r, theta, phi], axis=1)
60
61 @staticmethod
62 def spherical_to_cartesian(points):
63     """Convert spherical coordinates to cartesian
64     Args:
65         points: Array of shape (N, 3) containing [r, theta, phi] coordir
66     Returns:
67         Array of shape (N, 3) containing [x, y, z] coordinates
68     """
69     r, theta, phi = points[:, 0], points[:, 1], points[:, 2]
70     x = r * np.cos(theta) * np.sin(phi)
71     y = r * np.sin(theta) * np.sin(phi)
72     z = r * np.cos(phi)
73     return np.stack([x, y, z], axis=1)
74
75 @staticmethod
76 def get_cluster_colors(labels):
77     """Get colors for different clusters/labels"""
78     colors = ['r', 'b', 'g', 'c', 'm', 'darkorange', 'deepskyblue',
79              'blueviolet', 'crimson', 'orangered', 'k']
80     return [colors[label % len(colors)] for label in labels]
81
82 @staticmethod
83 def process_frame(data_point):
84     """Process a single frame of point cloud data
85     Returns normalized coordinates and spherical coordinates"""
86     points = data_point['new_x']
87
88     # Normalize cartesian coordinates
89     normalized = MMRUtils.normalize_points(points)
90
91     # Convert to spherical coordinates
92     spherical = MMRUtils.cartesian_to_spherical(points)
93
94     return {
95         'original': points,
96         'normalized': normalized,
97         'spherical': spherical
98     }
99
100 # Enhanced MMRDataAnalyzer class with utility functions
101 class EnhancedMMRAnalyzer(MMRDataAnalyzer):
102     def __init__(self, data_path):
103         super().__init__(data_path)
104         self.utils = MMRUtils()
105

```



```

106 def analyze_frame_geometry(self, frame_idx=0):
107     """Analyze geometric properties of a frame"""
108     data_point = self.train_data[frame_idx]
109     processed = self.utils.process_frame(data_point)
110
111     # Calculate geometric properties
112     points = processed['original']
113     center = np.mean(points, axis=0)
114     distances = np.linalg.norm(points - center, axis=1)
115
116     print("\nGeometric Analysis:")
117     print(f"Center of mass: {center}")
118     print(f"Mean distance from center: {np.mean(distances):.4f}")
119     print(f"Max distance from center: {np.max(distances):.4f}")
120
121     # Visualize in both coordinate systems
122     fig = plt.figure(figsize=(15, 5))
123
124     # Original coordinates
125     ax1 = fig.add_subplot(131, projection='3d')
126     ax1.scatter(points[:, 0], points[:, 1], points[:, 2])
127     ax1.set_title('Original Coordinates')
128
129     # Normalized coordinates
130     ax2 = fig.add_subplot(132, projection='3d')
131     norm_points = processed['normalized']
132     ax2.scatter(norm_points[:, 0], norm_points[:, 1], norm_points[:, 2])
133     ax2.set_title('Normalized Coordinates')
134
135     # Spherical coordinates
136     ax3 = fig.add_subplot(133, projection='3d')
137     sph_points = processed['spherical']
138     ax3.scatter(sph_points[:, 0] * np.sin(sph_points[:, 2]) * np.cos(sph_
139         sph_points[:, 0] * np.sin(sph_points[:, 2]) * np.sin(sph_
140         sph_points[:, 0] * np.cos(sph_points[:, 2]))
141     ax3.set_title('Spherical Coordinates')
142
143     plt.tight_layout()
144     plt.show()
145
146     return processed
147
148 # Example usage
149 if __name__ == "__main__":
150     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
151     analyzer = EnhancedMMRAnalyzer(data_path)
152
153     # Analyze a frame with new utilities
154     frame_data = analyzer.analyze_frame_geometry(0)
155
156     # Example of using utilities

```

```

157 points = analyzer.train_data[0]['new_x']
158 normalized = analyzer.utils.normalize_points(points)
159 spherical = analyzer.utils.cartesian_to_spherical(points)
160
161 print("\nPoint Cloud Statistics:")
162 print(f"Original range: [{points.min():.4f}, {points.max():.4f}]")
163 print(f"Normalized range: [{normalized.min():.4f}, {normalized.max():.4f}]")
164 print(f"Spherical coordinates shape: {spherical.shape}")

```




Geometric Analysis:

Center of mass: [ 0.04778343 0.53634458 -0.03896176]

Mean distance from center: 0.8495

Max distance from center: 3.3704



Point Cloud Statistics:

Original range: [-1.1581, 3.8908]

Normalized range: [0.0000, 1.0000]

Spherical coordinates shape: (110, 3)

15%

0.000000

1.174127

0.000000

## ✓ Plot data points

count 408430.000000 408430.000000 408430.000000

```

1 import os
2 import numpy as np
3 import pandas as pd
4 import pickle
5 import matplotlib.pyplot as plt
6 from mpl_toolkits.mplot3d import Axes3D
7

```

```

8 class MMRUtils:
9     @staticmethod
10     def normalize_points(points):
11         """Normalize point cloud data to [0,1] range"""
12         min_vals = np.min(points, axis=0)
13         max_vals = np.max(points, axis=0)
14         normalized = (points - min_vals) / (max_vals - min_vals)
15         return normalized
16
17     @staticmethod
18     def cartesian_to_spherical(points):
19         """Convert cartesian to spherical coordinates"""
20         x, y, z = points[:, 0], points[:, 1], points[:, 2]
21         r = np.sqrt(x**2 + y**2 + z**2)
22         theta = np.arctan2(y, x)
23         phi = np.arccos(z/r)
24         return np.stack([r, theta, phi], axis=1)
25
26     @staticmethod
27     def spherical_to_cartesian(points):
28         """Convert spherical to cartesian coordinates"""
29         r, theta, phi = points[:, 0], points[:, 1], points[:, 2]
30         x = r * np.sin(phi) * np.cos(theta)
31         y = r * np.sin(phi) * np.sin(theta)
32         z = r * np.cos(phi)
33         return np.stack([x, y, z], axis=1)
34
35 class EnhancedMMRAnalyzer:
36     def __init__(self, data_path):
37         self.utils = MMRUtils()
38         self.data_path = data_path
39         self.load_data()
40
41     def load_data(self):
42         """Load and verify data"""
43         try:
44             with open(self.data_path, 'rb') as f:
45                 self.data = pickle.load(f)
46                 self.train_data = self.data['train']
47                 print(f"Loaded {len(self.train_data)} training samples")
48         except Exception as e:
49             print(f"Error loading data: {e}")
50             raise
51
52     def visualize_frame(self, frame_idx=0):
53         """Basic frame visualization"""
54         try:
55             data_point = self.train_data[frame_idx]
56             points = data_point['new_x']
57
58             # Create simple 3D scatter plot

```

```

59         fig = plt.figure(figsize=(10, 10))
60         ax = fig.add_subplot(111, projection='3d')
61
62         # Plot points
63         scatter = ax.scatter(points[:, 0], points[:, 1], points[:, 2],
64                               c='blue', marker='.')
65
66         ax.set_xlabel('X')
67         ax.set_ylabel('Y')
68         ax.set_zlabel('Z')
69         ax.set_title(f'Frame {frame_idx} Point Cloud')
70
71         # Print statistics
72         print("\nFrame Statistics:")
73         print(f"Number of points: {len(points)}")
74         print(f"X range: [{points[:, 0].min():.4f}, {points[:, 0].max():.4f}]")
75         print(f"Y range: [{points[:, 1].min():.4f}, {points[:, 1].max():.4f}]")
76         print(f"Z range: [{points[:, 2].min():.4f}, {points[:, 2].max():.4f}]")
77
78         plt.show()
79         return points
80
81     except Exception as e:
82         print(f"Error visualizing frame: {e}")
83         raise
84
85     def visualize_frame_enhanced(self, frame_idx=0):
86         """Enhanced visualization with multiple views"""
87         try:
88             data_point = self.train_data[frame_idx]
89             points = data_point['new_x']
90
91             # Calculate geometric properties
92             center = np.mean(points, axis=0)
93             distances = np.linalg.norm(points - center, axis=1)
94
95             # Print analysis
96             print("\nGeometric Analysis:")
97             print(f"Center of mass: {center}")
98             print(f"Mean distance from center: {np.mean(distances):.4f}")
99             print(f"Max distance from center: {np.max(distances):.4f}")
100
101             # Create figure with three views
102             fig = plt.figure(figsize=(15, 5))
103
104             # Original coordinates
105             ax1 = fig.add_subplot(131, projection='3d')
106             ax1.scatter(points[:, 0], points[:, 1], points[:, 2], c='blue',
107                        marker='.')
108             ax1.set_title('Original Coordinates')
109             ax1.set_xlabel('X')
110             ax1.set_ylabel('Y')

```

```

110         ax1.set_zlabel('Z')
111
112         # Normalized coordinates
113         norm_points = self.utils.normalize_points(points)
114         ax2 = fig.add_subplot(132, projection='3d')
115         ax2.scatter(norm_points[:, 0], norm_points[:, 1], norm_points[:, 2],
116                    c='red', marker='.')
117         ax2.set_title('Normalized Coordinates')
118         ax2.set_xlabel('X')
119         ax2.set_ylabel('Y')
120         ax2.set_zlabel('Z')
121
122         # Spherical coordinates view
123         sph_points = self.utils.cartesian_to_spherical(points)
124         sph_cart = self.utils.spherical_to_cartesian(sph_points)
125         ax3 = fig.add_subplot(133, projection='3d')
126         ax3.scatter(sph_cart[:, 0], sph_cart[:, 1], sph_cart[:, 2],
127                    c='green', marker='.')
128         ax3.set_title('Spherical Coordinates')
129         ax3.set_xlabel('X')
130         ax3.set_ylabel('Y')
131         ax3.set_zlabel('Z')
132
133         plt.tight_layout()
134         plt.show()
135
136         # Print ranges
137         print("\nPoint Cloud Statistics:")
138         print(f"Original range: [{points.min():.4f}, {points.max():.4f}]")
139         print(f"Normalized range: [{norm_points.min():.4f}, {norm_points.max():.4f}]")
140         print(f"Spherical coordinates shape: {sph_points.shape}")
141
142         return points
143
144     except Exception as e:
145         print(f"Error in enhanced visualization: {e}")
146         raise
147
148     def compare_frames(self, frame_indices):
149         """Compare multiple frames"""
150         try:
151             n_frames = len(frame_indices)
152             fig = plt.figure(figsize=(5*n_frames, 5))
153
154             for i, idx in enumerate(frame_indices):
155                 ax = fig.add_subplot(1, n_frames, i+1, projection='3d')
156                 points = self.train_data[idx]['new_x']
157
158                 ax.scatter(points[:, 0], points[:, 1], points[:, 2],
159                           c='blue', marker='.')
160                 ax.set_title(f'Frame {idx}')

```

```

161         ax.set_xlabel('X')
162         ax.set_ylabel('Y')
163         ax.set_zlabel('Z')
164
165         plt.tight_layout()
166         plt.show()
167
168     except Exception as e:
169         print(f"Error comparing frames: {e}")
170         raise
171
172 # Example usage
173 if __name__ == "__main__":
174     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
175     analyzer = EnhancedMMRAnalyzer(data_path)
176
177     # Basic visualization
178     print("\nBasic Visualization:")
179     analyzer.visualize_frame(0)
180
181     # Enhanced visualization
182     print("\nEnhanced Visualization:")
183     analyzer.visualize_frame_enhanced(0)
184
185     # Compare multiple frames
186     print("\nComparing Multiple Frames:")
187     analyzer.compare_frames([0, 1, 2])

```

➡ Loaded 170336 training samples

Basic Visualization:

Frame Statistics:


Number of points: 110


X range: [-1.1581, 1.2027]

Y range: [0.0000, 3.8908]

Z range: [-0.8684, 0.6147]

Frame 0 Point Cloud





Enhanced Visualization:

Geometric Analysis:

Center of mass: [ 0.04778343 0.53634458 -0.03896176]

Mean distance from center: 0.8495

Max distance from center: 3.3704

<ipython-input-9-f8f139a9df25>:23: RuntimeWarning: invalid value encountere

$\phi = \arccos(z/r)$

Original Coordinates

Normalized Coordinates

Spherical Coordinates



## ✓ Choose frame window



1 WINDOW = 5



```

1 def analyze_mmr_windows(data_path, window_size=5):
2     """Analyze MMR data with sliding windows"""
3
4     # Load data
5     with open(data_path, 'rb') as f:
6         all_data = pickle.load(f)
7         train_data = all_data['train']
8
9     print(f"Analyzing {len(train_data)} frames with window size {window_size}")
10
11     # Single frame analysis
12     frame_points = []
13     for data_point in train_data:
14         points = data_point['new_x']

```

```

15         frame_points.append(len(points))
16
17     frame_series = pd.Series(frame_points)
18     print("\nPoints per Frame Statistics:")
19     print(frame_series.describe())
20
21     # Window analysis
22     window_points = []
23     num_windows = len(train_data) // window_size
24
25     for i in range(num_windows):
26         start_idx = i * window_size
27         end_idx = start_idx + window_size
28         window_count = sum(frame_points[start_idx:end_idx])
29         window_points.append(window_count)
30
31     window_series = pd.Series(window_points)
32     print(f"\nPoints per {window_size}-Frame Window Statistics:")
33     print(window_series.describe())
34
35     # Visualize first window
36     visualize_window(train_data, 0, window_size)
37
38     # Compare first few windows
39     compare_windows(train_data, [0, 1, 2], window_size)
40
41     return frame_series, window_series
42
43 def visualize_window(train_data, window_idx, window_size):
44     """Visualize all points in a window"""
45     start_idx = window_idx * window_size
46     end_idx = start_idx + window_size
47
48     # Collect points
49     all_points = []
50     frame_counts = []
51
52     for i in range(start_idx, min(end_idx, len(train_data))):
53         points = train_data[i]['new_x']
54         all_points.append(points)
55         frame_counts.append(len(points))
56
57     all_points = np.vstack(all_points)
58
59     # Create visualization
60     fig = plt.figure(figsize=(15, 5))
61
62     # 3D scatter plot
63     ax1 = fig.add_subplot(121, projection='3d')
64     scatter = ax1.scatter(all_points[:, 0], all_points[:, 1], all_points[:, 2],
65                          c='blue', marker='.', s=50)

```



```

66     ax1.set_xlabel('X')
67     ax1.set_ylabel('Y')
68     ax1.set_zlabel('Z')
69     ax1.set_title(f'Window {window_idx} (Frames {start_idx}-{end_idx-1})')
70     ax1.grid(True)
71
72     # Point count distribution
73     ax2 = fig.add_subplot(122)
74     ax2.bar(range(start_idx, end_idx), frame_counts)
75     ax2.set_xlabel('Frame Number')
76     ax2.set_ylabel('Number of Points')
77     ax2.set_title('Points per Frame in Window')
78     ax2.grid(True)
79
80     plt.tight_layout()
81     display(plt.gcf())
82     plt.close()
83
84     # Print statistics
85     print(f"\nWindow {window_idx} Statistics:")
86     print(f"Total frames: {len(frame_counts)}")
87     print(f"Total points: {len(all_points)}")
88     print(f"Average points per frame: {np.mean(frame_counts):.2f}")
89     print(f"Point range: [{all_points.min():.4f}, {all_points.max():.4f}]")
90
91     return all_points, frame_counts
92
93 def compare_windows(train_data, window_indices, window_size):
94     """Compare multiple windows"""
95     n_windows = len(window_indices)
96     fig = plt.figure(figsize=(5*n_windows, 5))
97
98     for i, idx in enumerate(window_indices):
99         start_idx = idx * window_size
100         end_idx = start_idx + window_size
101
102         # Collect window points
103         all_points = []
104         for j in range(start_idx, min(end_idx, len(train_data))):
105             points = train_data[j]['new_x']
106             all_points.append(points)
107         all_points = np.vstack(all_points)
108
109         # Plot
110         ax = fig.add_subplot(1, n_windows, i+1, projection='3d')
111         ax.scatter(all_points[:, 0], all_points[:, 1], all_points[:, 2],
112                   c='blue', marker='.', s=50)
113         ax.set_title(f'Window {idx}\n(Frames {start_idx}-{end_idx-1})')
114         ax.set_xlabel('X')
115         ax.set_ylabel('Y')
116         ax.set_zlabel('Z')

```

```

117         ax.grid(True)
118
119     plt.tight_layout()
120     display(plt.gcf())
121     plt.close()
122
123 # Example usage
124 if __name__ == "__main__":
125     # Set parameters
126     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
127     WINDOW_SIZE = 5
128
129     # Run analysis
130     frame_stats, window_stats = analyze_mmr_windows(data_path, WINDOW_SIZE)

```

➡ Analyzing 170336 frames with window size 5

Points per Frame Statistics:

```

count      170336.0
mean        110.0
std          0.0
min          110.0
25%          110.0
50%          110.0
75%          110.0
max          110.0
dtype: float64

```



Points per 5-Frame Window Statistics:

```

count      34067.0
mean        550.0
std          0.0
min          550.0
25%          550.0
50%          550.0
75%          550.0
max          550.0
dtype: float64

```

Window 0 (Frames 0-4)



Window 0 Statistics:


```

Total frames: 5
Total points: 550

```

Average points per frame: 110.00

Point range: [-1.3165, 4.7211]



## ✓ DBSCAN clustering

```
1 from sklearn.cluster import DBSCAN
```

```
1 # Define global variables
```

```
2 DBSCAN_EPS = 0.3
```

```
3 DBSCAN_SAMPLES = 6
```

```
1 import numpy as np
```

```
2 import matplotlib.pyplot as plt
```

```
3 from sklearn.preprocessing import MinMaxScaler
```

```
4
```

```
5 def get_colors(label_list):
```

```
6     """Get colors for cluster labels"""
```

```
7     color_list = ['r', 'b', 'g', 'c', 'm', 'darkorange', 'deepskyblue',
```

```
8                 'blueviolet', 'crimson', 'orangered', 'k']
```

```
9     return [color_list[label % len(color_list)] for label in label_list]
```

```
10
```

```
11 def normalize_weights(points):
```

```
12     """Normalize point weights to [0,1]"""
```

```
13     return MinMaxScaler().fit_transform(
```

```
14         np.linalg.norm(points, axis=1).reshape(-1, 1)
```

```
15     ).ravel()
```

```
16
```

```
17 def model_cluster(points, model, use_weights=True, show_plot=True, return_cl
```

```
18     """
```

```
19     Cluster point cloud data using the provided model
```

```
20
```

```
21     Args:
```

```
22         points: numpy array of shape (N, 3) containing point cloud coordinat
```

```

23     model: clustering model (e.g., DBSCAN, KMeans)
24     use_weights: whether to use point distances as weights
25     show_plot: whether to show clustering visualization
26     return_cluster: whether to return the clustering model
27
28 Returns:
29     clustering model if return_cluster is True
30 """
31 # Prepare weights if needed
32 if use_weights:
33     sample_weights = normalize_weights(points)
34 else:
35     sample_weights = None
36
37 # Perform clustering
38 clustering = model.fit(points, sample_weight=sample_weights)
39
40 # Visualize if requested
41 if show_plot:
42     fig = plt.figure(figsize=(12, 8))
43     ax = fig.add_subplot(111, projection='3d')
44
45     # Plot points colored by cluster
46     scatter = ax.scatter(points[:, 0], points[:, 1], points[:, 2],
47                          c=get_colors(clustering.labels_),
48                          marker='.',
49                          s=50)
50
51     # Add cluster centers if available (e.g., for KMeans)
52     if hasattr(model, 'cluster_centers_'):
53         centers = model.cluster_centers_
54         ax.scatter(centers[:, 0], centers[:, 1], centers[:, 2],
55                  c='black',
56                  marker='*',
57                  s=200,
58                  label='Cluster Centers')
59
60     # Configure plot
61     ax.set_xlabel('X')
62     ax.set_ylabel('Y')
63     ax.set_zlabel('Z')
64     ax.set_title(f'Clustering Results\n{model.__class__.__name__}')
65     ax.grid(True)
66
67     # Add statistics annotation
68     n_clusters = len(set(clustering.labels_)) - (1 if -1 in clustering.labels_ else 0)
69     stats_text = f'Number of clusters: {n_clusters}\n'
70     stats_text += f'Number of points: {len(points)}\n'
71     if -1 in clustering.labels_:
72         n_noise = np.sum(clustering.labels_ == -1)
73         stats_text += f'Noise points: {n_noise} ({n_noise/len(points)*100}%)

```

```

74         ax.text2D(0.02, 0.98, stats_text,
75                   transform=ax.transAxes,
76                   verticalalignment='top')
77
78     plt.tight_layout()
79     display(plt.gcf())
80     plt.close()
81
82     # Print cluster sizes
83     print("\nCluster Sizes:")
84     unique_labels = sorted(set(clustering.labels_))
85     for label in unique_labels:
86         count = np.sum(clustering.labels_ == label)
87         if label == -1:
88             print(f"Noise points: {count} ({count/len(points)*100:.1f}%)
89         else:
90             print(f"Cluster {label}: {count} points ({count/len(points)*100:.1f}%)
91
92     if return_cluster:
93         return clustering
94
95 # Example usage
96 if __name__ == "__main__":
97     # Load your data
98     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dataset.pkl'
99     with open(data_path, 'rb') as f:
100         data = pickle.load(f)
101
102     # Get points from first frame
103     points = data['train'][0]['new_x']
104
105     # Try different clustering models
106     from sklearn.cluster import DBSCAN, KMeans
107
108     # DBSCAN clustering
109     dbscan = DBSCAN(eps=0.3, min_samples=5)
110     print("\nDBSCAN Clustering:")
111     dbscan_result = model_cluster(points, dbscan, use_weights=True, return_cluster=True)
112
113     # KMeans clustering
114     kmeans = KMeans(n_clusters=5, random_state=42)
115     print("\nKMeans Clustering:")
116     kmeans_result = model_cluster(points, kmeans, use_weights=True, return_cluster=True)

```




DBSCAN Clustering:

### Clustering Results DBSCAN

Number of clusters: 0  
 Number of points: 110  
 Noise points: 110 (100.0%)





Cluster Sizes:  
Noise points: 110 (100.0%)


KMeans Clustering:

Clustering Results  
KMeans

Number of clusters: 5  
Number of points: 110



✓ Compare with and without sample\_weight



```
1 def cluster_window(data_points, start_frame, window_size, eps=0.3, min_sampl
```

```

2      """
3      Cluster points in a specific frame window
4
5      Args:
6          data_points: List of frame data points
7          start_frame: Starting frame index
8          window_size: Number of frames in window
9          eps: DBSCAN epsilon parameter
10         min_samples: DBSCAN min_samples parameter
11         use_weights: Whether to use intensity weights
12     """
13     # Collect points from window
14     window_points = []
15     frame_indices = []
16
17     end_frame = start_frame + window_size
18     for i in range(start_frame, end_frame):
19         if i < len(data_points):
20             points = data_points[i]['new_x']
21             window_points.append(points)
22             frame_indices.extend([i] * len(points))
23
24     window_points = np.vstack(window_points)
25     frame_indices = np.array(frame_indices)
26
27     # Create DBSCAN model
28     dbscan = DBSCAN(eps=eps, min_samples=min_samples)
29
30     # Prepare sample weights if needed
31     if use_weights:
32         weights = normalize_weights(window_points)
33     else:
34         weights = None
35
36     # Perform clustering
37     clustering = dbscan.fit(window_points, sample_weight=weights)
38
39     # Visualize results
40     fig = plt.figure(figsize=(20, 6))
41
42     # Original points colored by frame
43     ax1 = fig.add_subplot(131, projection='3d')
44     scatter1 = ax1.scatter(window_points[:, 0], window_points[:, 1], window_
45                             c=frame_indices, cmap='viridis',
46                             marker='.', s=50)
47     ax1.set_title('Points Colored by Frame')
48     ax1.set_xlabel('X')
49     ax1.set_ylabel('Y')
50     ax1.set_zlabel('Z')
51     plt.colorbar(scatter1, label='Frame Number')
52

```

```

53 # Clustering without weights
54 dbscan_no_weights = DBSCAN(eps=eps, min_samples=min_samples)
55 labels_no_weights = dbscan_no_weights.fit_predict(window_points)
56
57 ax2 = fig.add_subplot(132, projection='3d')
58 scatter2 = ax2.scatter(window_points[:, 0], window_points[:, 1], window_
59                        c=get_colors(labels_no_weights),
60                        marker='.', s=50)
61 ax2.set_title('Clustering without Weights')
62 ax2.set_xlabel('X')
63 ax2.set_ylabel('Y')
64 ax2.set_zlabel('Z')
65
66 # Clustering with weights
67 ax3 = fig.add_subplot(133, projection='3d')
68 scatter3 = ax3.scatter(window_points[:, 0], window_points[:, 1], window_
69                        c=get_colors(clustering.labels_),
70                        marker='.', s=50)
71 ax3.set_title('Clustering with Weights')
72 ax3.set_xlabel('X')
73 ax3.set_ylabel('Y')
74 ax3.set_zlabel('Z')
75
76 plt.tight_layout()
77 display(plt.gcf())
78 plt.close()
79
80 # Print statistics
81 print(f"\nWindow Statistics (Frames {start_frame}-{end_frame-1}):")
82 print(f"Total points: {len(window_points)}")
83
84 print("\nClustering without weights:")
85 n_clusters_no_weights = len(set(labels_no_weights)) - (1 if -1 in labels_
86 print(f"Number of clusters: {n_clusters_no_weights}")
87 if -1 in labels_no_weights:
88     n_noise = np.sum(labels_no_weights == -1)
89     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
90
91 print("\nClustering with weights:")
92 n_clusters = len(set(clustering.labels_)) - (1 if -1 in clustering.label
93 print(f"Number of clusters: {n_clusters}")
94 if -1 in clustering.labels_:
95     n_noise = np.sum(clustering.labels_ == -1)
96     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
97
98 return clustering, window_points, frame_indices
99
100 def analyze_window_clusters(clustering, window_points, frame_indices):
101     """Analyze clusters in a window"""
102     unique_labels = sorted(set(clustering.labels_))
103

```






```

104 # Create visualization
105 n_clusters = len(unique_labels)
106 fig_cols = min(3, n_clusters)
107 fig_rows = (n_clusters + fig_cols - 1) // fig_cols
108
109 fig = plt.figure(figsize=(6*fig_cols, 5*fig_rows))
110
111 for i, label in enumerate(unique_labels):
112     mask = clustering.labels_ == label
113     cluster_points = window_points[mask]
114     cluster_frames = frame_indices[mask]
115
116     ax = fig.add_subplot(fig_rows, fig_cols, i+1, projection='3d')
117     scatter = ax.scatter(cluster_points[:, 0],
118                         cluster_points[:, 1],
119                         cluster_points[:, 2],
120                         c=cluster_frames,
121                         cmap='viridis',
122                         marker='.',
123                         s=50)
124
125     title = "Noise Points" if label == -1 else f"Cluster {label}"
126     title += f"\n{len(cluster_points)} points"
127     ax.set_title(title)
128     ax.set_xlabel('X')
129     ax.set_ylabel('Y')
130     ax.set_zlabel('Z')
131     plt.colorbar(scatter, label='Frame Number')
132
133 plt.tight_layout()
134 display(plt.gcf())
135 plt.close()
136
137 # Example usage
138 if __name__ == "__main__":
139     # Parameters
140     WINDOW = 5
141     DBSCAN_EPS = 0.3
142     DBSCAN_SAMPLES = 5
143     START_FRAME = 0
144
145     # Load data
146     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
147     with open(data_path, 'rb') as f:
148         data = pickle.load(f)
149
150     # Perform clustering
151     clustering, points, frames = cluster_window(
152         data['train'],
153         start_frame=START_FRAME,
154         window_size=WINDOW,

```

```
155         eps=DBSCAN_EPS,  
156         min_samples=DBSCAN_SAMPLES  
157     )  
158  
159     # Analyze clusters  
160     analyze_window_clusters(clustering, points, frames)
```



Window Statistics (Frames 0-4):

Total points: 550

Clustering without weights:




Number of clusters: 7

Noise points: 20 (3.6%)

Clustering with weights:

Number of clusters: 2

Noise points: 459 (83.5%)



```
1 def cluster_window(data_points, start_frame, window_size, eps=0.3, min_sampl
2     """
3     Cluster points in a specific frame window
4
5     Args:
```

```

6         data_points: List of frame data points
7         start_frame: Starting frame index
8         window_size: Number of frames in window
9         eps: DBSCAN epsilon parameter
10        min_samples: DBSCAN min_samples parameter
11        use_weights: Whether to use intensity weights
12    """
13    # Collect points from window
14    window_points = []
15    frame_indices = []
16
17    end_frame = start_frame + window_size
18    for i in range(start_frame, end_frame):
19        if i < len(data_points):
20            points = data_points[i]['new_x']
21            window_points.append(points)
22            frame_indices.extend([i] * len(points))
23
24    window_points = np.vstack(window_points)
25    frame_indices = np.array(frame_indices)
26
27    # Create DBSCAN model
28    dbscan = DBSCAN(eps=eps, min_samples=min_samples)
29
30    # Prepare sample weights if needed
31    if use_weights:
32        weights = normalize_weights(window_points)
33    else:
34        weights = None
35
36    # Perform clustering
37    clustering = dbscan.fit(window_points, sample_weight=weights)
38
39    # Visualize results
40    fig = plt.figure(figsize=(20, 6))
41
42    # Original points colored by frame
43    ax1 = fig.add_subplot(131, projection='3d')
44    scatter1 = ax1.scatter(window_points[:, 0], window_points[:, 1], window_
45                           c=frame_indices, cmap='viridis',
46                           marker='.', s=50)
47    ax1.set_title('Points Colored by Frame')
48    ax1.set_xlabel('X')
49    ax1.set_ylabel('Y')
50    ax1.set_zlabel('Z')
51    plt.colorbar(scatter1, label='Frame Number')
52
53    # Clustering without weights
54    dbscan_no_weights = DBSCAN(eps=eps, min_samples=min_samples)
55    labels_no_weights = dbscan_no_weights.fit_predict(window_points)
56

```

```

57 ax2 = fig.add_subplot(132, projection='3d')
58 scatter2 = ax2.scatter(window_points[:, 0], window_points[:, 1], window_
59                          c=get_colors(labels_no_weights),
60                          marker='.', s=50)
61 ax2.set_title('Clustering without Weights')
62 ax2.set_xlabel('X')
63 ax2.set_ylabel('Y')
64 ax2.set_zlabel('Z')
65
66 # Clustering with weights
67 ax3 = fig.add_subplot(133, projection='3d')
68 scatter3 = ax3.scatter(window_points[:, 0], window_points[:, 1], window_
69                          c=get_colors(clustering.labels_),
70                          marker='.', s=50)
71 ax3.set_title('Clustering with Weights')
72 ax3.set_xlabel('X')
73 ax3.set_ylabel('Y')
74 ax3.set_zlabel('Z')
75
76 plt.tight_layout()
77 display(plt.gcf())
78 plt.close()
79
80 # Print statistics
81 print(f"\nWindow Statistics (Frames {start_frame}-{end_frame-1}):")
82 print(f"Total points: {len(window_points)}")
83
84 print("\nClustering without weights:")
85 n_clusters_no_weights = len(set(labels_no_weights)) - (1 if -1 in labels
86 print(f"Number of clusters: {n_clusters_no_weights}")
87 if -1 in labels_no_weights:
88     n_noise = np.sum(labels_no_weights == -1)
89     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
90
91 print("\nClustering with weights:")
92 n_clusters = len(set(clustering.labels_)) - (1 if -1 in clustering.label
93 print(f"Number of clusters: {n_clusters}")
94 if -1 in clustering.labels_:
95     n_noise = np.sum(clustering.labels_ == -1)
96     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
97
98 return clustering, window_points, frame_indices
99
100 def analyze_window_clusters(clustering, window_points, frame_indices):
101     """Analyze clusters in a window"""
102     unique_labels = sorted(set(clustering.labels_))
103
104     # Create visualization
105     n_clusters = len(unique_labels)
106     fig_cols = min(3, n_clusters)
107     fig_rows = (n_clusters + fig_cols - 1) // fig_cols

```


```

108
109     fig = plt.figure(figsize=(6*fig_cols, 5*fig_rows))
110
111     for i, label in enumerate(unique_labels):
112         mask = clustering.labels_ == label
113         cluster_points = window_points[mask]
114         cluster_frames = frame_indices[mask]
115
116         ax = fig.add_subplot(fig_rows, fig_cols, i+1, projection='3d')
117         scatter = ax.scatter(cluster_points[:, 0],
118                             cluster_points[:, 1],
119                             cluster_points[:, 2],
120                             c=cluster_frames,
121                             cmap='viridis',
122                             marker='.',
123                             s=50)
124
125         title = "Noise Points" if label == -1 else f"Cluster {label}"
126         title += f"\n{len(cluster_points)} points"
127         ax.set_title(title)
128         ax.set_xlabel('X')
129         ax.set_ylabel('Y')
130         ax.set_zlabel('Z')
131         plt.colorbar(scatter, label='Frame Number')
132
133     plt.tight_layout()
134     display(plt.gcf())
135     plt.close()
136
137 # Example usage
138 if __name__ == "__main__":
139     # Parameters
140     WINDOW = 5
141     DBSCAN_EPS = 0.3
142     DBSCAN_SAMPLES = 5
143     START_FRAME = 5
144
145     # Load data
146     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
147     with open(data_path, 'rb') as f:
148         data = pickle.load(f)
149
150     # Perform clustering
151     clustering, points, frames = cluster_window(
152         data['train'],
153         start_frame=START_FRAME,
154         window_size=WINDOW,
155         eps=DBSCAN_EPS,
156         min_samples=DBSCAN_SAMPLES
157     )
158

```

159  
160

```
# Analyze clusters  
analyze_window_clusters(clustering, points, frames)
```



Window Statistics (Frames 5-9):

Total points: 550

Clustering without weights:


Number of clusters: 8

Noise points: 35 (6.4%)

Clustering with weights:

Number of clusters: 2

Noise points: 466 (84.7%)



```
1 def cluster_window(data_points, start_frame, window_size, eps=0.3, min_sampl  
2     """
```

```

3   Cluster points in a specific frame window
4
5   Args:
6       data_points: List of frame data points
7       start_frame: Starting frame index
8       window_size: Number of frames in window
9       eps: DBSCAN epsilon parameter
10      min_samples: DBSCAN min_samples parameter
11      use_weights: Whether to use intensity weights
12      """"
13      # Collect points from window
14      window_points = []
15      frame_indices = []
16
17      end_frame = start_frame + window_size
18      for i in range(start_frame, end_frame):
19          if i < len(data_points):
20              points = data_points[i]['new_x']
21              window_points.append(points)
22              frame_indices.extend([i] * len(points))
23
24      window_points = np.vstack(window_points)
25      frame_indices = np.array(frame_indices)
26
27      # Create DBSCAN model
28      dbscan = DBSCAN(eps=eps, min_samples=min_samples)
29
30      # Prepare sample weights if needed
31      if use_weights:
32          weights = normalize_weights(window_points)
33      else:
34          weights = None
35
36      # Perform clustering
37      clustering = dbscan.fit(window_points, sample_weight=weights)
38
39      # Visualize results
40      fig = plt.figure(figsize=(20, 6))
41
42      # Original points colored by frame
43      ax1 = fig.add_subplot(131, projection='3d')
44      scatter1 = ax1.scatter(window_points[:, 0], window_points[:, 1], window_
45                             c=frame_indices, cmap='viridis',
46                             marker='.', s=50)
47      ax1.set_title('Points Colored by Frame')
48      ax1.set_xlabel('X')
49      ax1.set_ylabel('Y')
50      ax1.set_zlabel('Z')
51      plt.colorbar(scatter1, label='Frame Number')
52
53      # Clustering without weights

```



```

54 dbscan_no_weights = DBSCAN(eps=eps, min_samples=min_samples)
55 labels_no_weights = dbscan_no_weights.fit_predict(window_points)
56
57 ax2 = fig.add_subplot(132, projection='3d')
58 scatter2 = ax2.scatter(window_points[:, 0], window_points[:, 1], window_
59                        c=get_colors(labels_no_weights),
60                        marker='.', s=50)
61 ax2.set_title('Clustering without Weights')
62 ax2.set_xlabel('X')
63 ax2.set_ylabel('Y')
64 ax2.set_zlabel('Z')
65
66 # Clustering with weights
67 ax3 = fig.add_subplot(133, projection='3d')
68 scatter3 = ax3.scatter(window_points[:, 0], window_points[:, 1], window_
69                        c=get_colors(clustering.labels_),
70                        marker='.', s=50)
71 ax3.set_title('Clustering with Weights')
72 ax3.set_xlabel('X')
73 ax3.set_ylabel('Y')
74 ax3.set_zlabel('Z')
75
76 plt.tight_layout()
77 display(plt.gcf())
78 plt.close()
79
80 # Print statistics
81 print(f"\nWindow Statistics (Frames {start_frame}-{end_frame-1}):")
82 print(f"Total points: {len(window_points)}")
83
84 print("\nClustering without weights:")
85 n_clusters_no_weights = len(set(labels_no_weights)) - (1 if -1 in labels
86 print(f"Number of clusters: {n_clusters_no_weights}")
87 if -1 in labels_no_weights:
88     n_noise = np.sum(labels_no_weights == -1)
89     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
90
91 print("\nClustering with weights:")
92 n_clusters = len(set(clustering.labels_)) - (1 if -1 in clustering.label
93 print(f"Number of clusters: {n_clusters}")
94 if -1 in clustering.labels_:
95     n_noise = np.sum(clustering.labels_ == -1)
96     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
97
98 return clustering, window_points, frame_indices
99
100 def analyze_window_clusters(clustering, window_points, frame_indices):
101     """Analyze clusters in a window"""
102     unique_labels = sorted(set(clustering.labels_))
103
104     # Create visualization

```

```


105     n_clusters = len(unique_labels)
106     fig_cols = min(3, n_clusters)
107     fig_rows = (n_clusters + fig_cols - 1) // fig_cols
108
109     fig = plt.figure(figsize=(6*fig_cols, 5*fig_rows))
110
111     for i, label in enumerate(unique_labels):
112         mask = clustering.labels_ == label
113         cluster_points = window_points[mask]
114         cluster_frames = frame_indices[mask]
115
116         ax = fig.add_subplot(fig_rows, fig_cols, i+1, projection='3d')
117         scatter = ax.scatter(cluster_points[:, 0],
118                             cluster_points[:, 1],
119                             cluster_points[:, 2],
120                             c=cluster_frames,
121                             cmap='viridis',
122                             marker='.',
123                             s=50)
124
125         title = "Noise Points" if label == -1 else f"Cluster {label}"
126         title += f"\n{len(cluster_points)} points"
127         ax.set_title(title)
128         ax.set_xlabel('X')
129         ax.set_ylabel('Y')
130         ax.set_zlabel('Z')
131         plt.colorbar(scatter, label='Frame Number')
132
133     plt.tight_layout()
134     display(plt.gcf())
135     plt.close()
136
137 # Example usage
138 if __name__ == "__main__":
139     # Parameters
140     WINDOW = 5
141     DBSCAN_EPS = 0.3
142     DBSCAN_SAMPLES = 5
143     START_FRAME = 10
144
145     # Load data
146     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
147     with open(data_path, 'rb') as f:
148         data = pickle.load(f)
149
150     # Perform clustering
151     clustering, points, frames = cluster_window(
152         data['train'],
153         start_frame=START_FRAME,
154         window_size=WINDOW,
155         eps=DBSCAN_EPS,

```

```

156         min_samples=DBSCAN_SAMPLES
157     )
158
159     # Analyze clusters
160     analyze_window_clusters(clustering, points, frames)


```



Window Statistics (Frames 10-14):  
Total points: 550

Clustering without weights:  
Number of clusters: 7  
Noise points: 31 (5.6%)

Clustering with weights:  
Number of clusters: 2  
Noise points: 460 (83.6%)



```

1 def cluster_window(data_points, start_frame, window_size, eps=0.3, min_sampl
2     """
3     Cluster points in a specific frame window
4
5     Args:
6         data_points: List of frame data points
7         start_frame: Starting frame index
8         window_size: Number of frames in window
9         eps: DBSCAN epsilon parameter
10        min_samples: DBSCAN min_samples parameter
11        use_weights: Whether to use intensity weights
12    """
13    # Collect points from window
14    window_points = []
15    frame_indices = []
16
17    end_frame = start_frame + window_size
18    for i in range(start_frame, end_frame):
19        if i < len(data_points):
20            points = data_points[i]['new_x']
21            window_points.append(points)
22            frame_indices.extend([i] * len(points))
23
24    window_points = np.vstack(window_points)
25    frame_indices = np.array(frame_indices)
26
27    # Create DBSCAN model
28    dbscan = DBSCAN(eps=eps, min_samples=min_samples)
29
30    # Prepare sample weights if needed
31    if use_weights:
32        weights = normalize_weights(window_points)
33    else:
34        weights = None
35
36    # Perform clustering
37    clustering = dbscan.fit(window_points, sample_weight=weights)
38
39    # Visualize results
40    fig = plt.figure(figsize=(20, 6))
41
42    # Original points colored by frame
43    ax1 = fig.add_subplot(131, projection='3d')
44    scatter1 = ax1.scatter(window_points[:, 0], window_points[:, 1], window_
45                           c=frame_indices, cmap='viridis',
46                           marker='.', s=50)
47    ax1.set_title('Points Colored by Frame')
48    ax1.set_xlabel('X')
49    ax1.set_ylabel('Y')
50    ax1.set_zlabel('Z')
51    plt.colorbar(scatter1, label='Frame Number')

```

```

52
53 # Clustering without weights
54 dbscan_no_weights = DBSCAN(eps=eps, min_samples=min_samples)
55 labels_no_weights = dbscan_no_weights.fit_predict(window_points)
56
57 ax2 = fig.add_subplot(132, projection='3d')
58 scatter2 = ax2.scatter(window_points[:, 0], window_points[:, 1], window_
59                        c=get_colors(labels_no_weights),
60                        marker='.', s=50)
61 ax2.set_title('Clustering without Weights')
62 ax2.set_xlabel('X')
63 ax2.set_ylabel('Y')
64 ax2.set_zlabel('Z')
65
66 # Clustering with weights
67 ax3 = fig.add_subplot(133, projection='3d')
68 scatter3 = ax3.scatter(window_points[:, 0], window_points[:, 1], window_
69                        c=get_colors(clustering.labels_),
70                        marker='.', s=50)
71 ax3.set_title('Clustering with Weights')
72 ax3.set_xlabel('X')
73 ax3.set_ylabel('Y')
74 ax3.set_zlabel('Z')
75
76 plt.tight_layout()
77 display(plt.gcf())
78 plt.close()
79
80 # Print statistics
81 print(f"\nWindow Statistics (Frames {start_frame}-{end_frame-1}):")
82 print(f"Total points: {len(window_points)}")
83
84 print("\nClustering without weights:")
85 n_clusters_no_weights = len(set(labels_no_weights)) - (1 if -1 in labels_
86 print(f"Number of clusters: {n_clusters_no_weights}")
87 if -1 in labels_no_weights:
88     n_noise = np.sum(labels_no_weights == -1)
89     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
90
91 print("\nClustering with weights:")
92 n_clusters = len(set(clustering.labels_)) - (1 if -1 in clustering.label
93 print(f"Number of clusters: {n_clusters}")
94 if -1 in clustering.labels_:
95     n_noise = np.sum(clustering.labels_ == -1)
96     print(f"Noise points: {n_noise} ({n_noise/len(window_points)*100:.1f
97
98 return clustering, window_points, frame_indices
99
100 def analyze_window_clusters(clustering, window_points, frame_indices):
101     """Analyze clusters in a window"""
102     unique_labels = sorted(set(clustering.labels_))

```

```


103
104 # Create visualization
105 n_clusters = len(unique_labels)
106 fig_cols = min(3, n_clusters)
107 fig_rows = (n_clusters + fig_cols - 1) // fig_cols
108
109 fig = plt.figure(figsize=(6*fig_cols, 5*fig_rows))
110
111 for i, label in enumerate(unique_labels):
112     mask = clustering.labels_ == label
113     cluster_points = window_points[mask]
114     cluster_frames = frame_indices[mask]
115
116     ax = fig.add_subplot(fig_rows, fig_cols, i+1, projection='3d')
117     scatter = ax.scatter(cluster_points[:, 0],
118                         cluster_points[:, 1],
119                         cluster_points[:, 2],
120                         c=cluster_frames,
121                         cmap='viridis',
122                         marker='.',
123                         s=50)
124
125     title = "Noise Points" if label == -1 else f"Cluster {label}"
126     title += f"\n{len(cluster_points)} points"
127     ax.set_title(title)
128     ax.set_xlabel('X')
129     ax.set_ylabel('Y')
130     ax.set_zlabel('Z')
131     plt.colorbar(scatter, label='Frame Number')
132
133 plt.tight_layout()
134 display(plt.gcf())
135 plt.close()
136
137 # Example usage
138 if __name__ == "__main__":
139     # Parameters
140     WINDOW = 5
141     DBSCAN_EPS = 0.3
142     DBSCAN_SAMPLES = 5
143     START_FRAME = 15
144
145     # Load data
146     data_path = '/content/drive/MyDrive/action/data/processed/mmr_action/dat
147     with open(data_path, 'rb') as f:
148         data = pickle.load(f)
149
150     # Perform clustering
151     clustering, points, frames = cluster_window(
152         data['train'],
153         start_frame=START_FRAME,

```

```

154     window_size=WINDOW,
155     eps=DBSCAN_EPS,
156     min_samples=DBSCAN_SAMPLES
157 )
158
159 # Analyze clusters
160 analyze_window_clusters(clustering, points, frames)


```



Window Statistics (Frames 15-19):  
Total points: 550

Clustering without weights:  
Number of clusters: 6  
Noise points: 28 (5.1%)

Clustering with weights:  
Number of clusters: 3  
Noise points: 449 (81.6%)



## Change DBSCAN eps, min\_samples [TODO]

- ✓ Estimate boundary for each cluster (extension, orientation)

[illegible]



```

32     if return_cluster:
33         return clustering
34
35 def analyze_window(data, start_frame, window_size=5):
36     """Analyze a window of frames"""
37     # Collect points from window frames
38     window_points = []
39     for i in range(start_frame, start_frame + window_size):
40         if i < len(data):
41             points = data[i]['new_x']
42             window_points.append(points)
43
44     # Stack all points
45     window_points = np.vstack(window_points)
46
47     return window_points
48
49 # Example usage
50 if __name__ == "__main__":
51     # Load data
52     with open('/content/drive/MyDrive/action/data/processed/mmr_action/data.
53         data = pickle.load(f)
54     train_data = data['train']
55
56     # Set parameters
57     WINDOW = 5
58     DBSCAN_EPS = 0.3
59     DBSCAN_SAMPLES = 6
60
61     # Process windows
62     for startFrame in range(0, 20, WINDOW):
63         print(f"\nAnalyzing frames {startFrame} to {startFrame+WINDOW-1}")
64
65         # Get window points
66         window_points = analyze_window(train_data, startFrame, WINDOW)
67
68         # Create and apply DBSCAN
69         dbscan = DBSCAN(eps=DBSCAN_EPS, min_samples=DBSCAN_SAMPLES)
70         clustering = ModelCluster(window_points, dbscan,
71                                 sample_weight=True,
72                                 show_plot=False,
73                                 return_cluster=True)
74
75         # Analyze clusters
76         print("Cluster Analysis:")
77         ClusterAnalysis(clustering.labels_)

```



Analyzing frames 0 to 4

Cluster Analysis:

-----

-

**NameError** Traceback (most recent call  
last)

<ipython-input-27-34b188df72e7> in <cell line: 50>()

75 # Analyze clusters

76 print("Cluster Analysis:")

---> 77 ClusterAnalysis(clustering.labels\_)

**NameError:** name 'ClusterAnalysis' is not defined

```

1 # Parameters
2 WINDOW = 5
3 startFrame = 0
4 DBSCAN_EPS = 0.3
5 DBSCAN_SAMPLES = 6
6
7 # Load data
8 # Load data
9 with open('/content/drive/MyDrive/action/data/processed/mmr_action/data.pkl'
10         data = pickle.load(f)
11 train_data = data['train']
12
13 def Weight(datalist):
14     """Normalize intensity values to [0,1] for weights"""
15     return MinMaxScaler().fit_transform(
16         np.asarray(datalist['intensity']).reshape(-1,1)
17     ).reshape(1,-1)[0]
18
19 def ClusterCenter(points, weights):
20     """Calculate weighted centroid position of cluster"""
21     return np.average(points, axis=0, weights=weights)
22
23 # Get points for the window
24 window_points = []
25 for i in range(startFrame, startFrame + WINDOW):
26     if i < len(train_data):
27         points = train_data[i]['new_x']
28         window_points.append(points)
29 window_points = np.vstack(window_points)
30
31 # Perform clustering
32 dbscan = DBSCAN(eps=DBSCAN_EPS, min_samples=DBSCAN_SAMPLES)
33 clustering = ModelCluster(window_points, dbscan,
34                             sample_weight=True,
35                             show_plot=False,
36                             return_cluster=True)
37
38 # Get points for cluster 0
39 cluster_mask = clustering.labels_ == 0
40 cluster_points = window_points[cluster_mask]
41
42 # Calculate cluster center
43 weights = normalize_weights(cluster_points) # Using the normalize function
44 cluster_center = ClusterCenter(cluster_points, weights)
45 print("Cluster 0 center:", cluster_center)

```

```

➡ Cluster 0 center: [ 1.33793459  2.73593783 -0.27574565]

```

```

1 import numpy as np
2 import pandas as pd

```

```

3
4 def debug_clustering(clusterlist):
5     # Print basic stats
6     print(f"Number of points: {len(clusterlist)}")
7     print("\nPoint statistics:")
8     print(clusterlist.describe())
9
10    # Check weights
11    points = np.array(clusterlist[['x','y','z']])
12    weights = np.linalg.norm(points, axis=1)
13    print("\nWeight statistics:")
14    print(f"Min weight: {weights.min()}")
15    print(f"Max weight: {weights.max()}")
16    print(f"Mean weight: {weights.mean()}")
17
18    # Check cluster center
19    center = ClusterCenter(clusterlist)
20    print("\nCluster center:", center)
21
22    # Check covariance calculation
23    weights = Weight(clusterlist)
24    cov = CalcCovariance(clusterlist, center, weights)
25    print("\nCovariance matrix:")
26    print(cov)
27
28 # Add this before calculating extensions:
29 debug_clustering(clusterlist)

```

➡ Number of points: 395

Point statistics:

	x	y	z
count	395.0	395.0	395.0
mean	0.0	0.0	0.0
std	0.0	0.0	0.0
min	0.0	0.0	0.0
25%	0.0	0.0	0.0
50%	0.0	0.0	0.0
75%	0.0	0.0	0.0
max	0.0	0.0	0.0

Weight statistics:

Min weight: 0.0

Max weight: 0.0

Mean weight: 0.0

Cluster center: [0. 0. 0.]

Covariance matrix:

```

[[0. 0. 0.]
 [0. 0. 0.]
 [0. 0. 0.]]

```

```

1 # After loading data
2 print("Raw point statistics:")
3 for i in range(5):
4     points = train_data[i]['new_x']
5     print(f"\nFrame {i}:")
6     print(f"Number of points: {len(points)}")
7     print(f"Min values: {np.min(points, axis=0)}")
8     print(f"Max values: {np.max(points, axis=0)}")
9
10 # Before DBSCAN
11 print("\nWindow points before clustering:")
12 print(f"Shape: {window_points.shape}")
13 print(f"Non-zero points: {np.count_nonzero(window_points)}")
14 print(f"Sample of points:\n{window_points[:5]}")

```

➡ Raw point statistics:

```

Frame 0:
Number of points: 110
Min values: [-1.15814066  0.          -0.86839569]
Max values: [1.20268464  3.89084435  0.61470288]

```

```

Frame 1:
Number of points: 110
Min values: [-0.9290579  0.          -1.2256074]
Max values: [1.30068111  4.72105169  0.69817191]

```

```

Frame 2:
Number of points: 110
Min values: [-0.83615208  0.          -1.01736093]
Max values: [1.08432519  2.75244379  1.11984921]

```

```

Frame 3:
Number of points: 110
Min values: [-0.74324632  0.          -0.5372054 ]
Max values: [1.37195122  2.82800937  0.56259519]

```

```

Frame 4:
Number of points: 110
Min values: [-0.91633111  0.          -1.31651485]
Max values: [1.28286362  4.65428591  0.98492074]

```

```

Window points before clustering:
Shape: (550, 3)
Non-zero points: 456
Sample of points:
[[0. 0. 0.]
 [0. 0. 0.]
 [0. 0. 0.]
 [0. 0. 0.]
 [0. 0. 0.]]

```

---

```

1 import numpy as np
2 import pandas as pd

```

```

3 from sklearn.preprocessing import MinMaxScaler
4 from scipy.optimize import linear_sum_assignment
5 from sklearn.cluster import DBSCAN
6
7 def HorToVer(array):
8     return array.reshape(-1,1)
9
10 def VerToHor(array):
11     return array.reshape(1,-1)
12
13 def VectorAngle(vec1, vec2):
14     return np.abs(np.dot(vec1, vec2))/(np.linalg.norm(vec1)*np.linalg.norm(vec2))
15
16 def Weight(clusterlist):
17     points = np.array(clusterlist[['x','y','z']])
18     weights = np.linalg.norm(points, axis=1)
19     weights = weights + 1e-8
20     return weights / np.sum(weights)
21
22 def ClusterCenter(clusterlist):
23     weights = Weight(clusterlist)
24     if np.all(weights == 0):
25         return np.mean(clusterlist[['x','y','z']], axis=0)
26     return np.average(clusterlist[['x','y','z']], axis=0, weights=weights)
27
28 def CalcCovariance(clusterlist, cluster_center, cluster_pt_weight, orientation):
29     if orientation:
30         cluster_cov = np.zeros((3,3))
31         for i in range(len(clusterlist.index)):
32             pt_diff = np.array(clusterlist[['x','y','z']])[i]-cluster_center
33             cluster_cov += cluster_pt_weight[i]*np.dot(HorToVer(pt_diff), VerToHor(pt_diff))
34     else:
35         cluster_cov = np.zeros(3)
36         for i in range(len(clusterlist.index)):
37             cluster_cov[0] += cluster_pt_weight[i]*np.dot(np.array(clusterlist[['x','y','z']])[i]-cluster_center,
38                                                             np.array(clusterlist[['x','y','z']])[i]-cluster_center)
39             cluster_cov[1] += cluster_pt_weight[i]*np.dot(np.array(clusterlist[['x','y','z']])[i]-cluster_center,
40                                                             np.array(clusterlist[['x','y','z']])[i]-cluster_center)
41             cluster_cov[2] += cluster_pt_weight[i]*np.dot(np.array(clusterlist[['x','y','z']])[i]-cluster_center,
42                                                             np.array(clusterlist[['x','y','z']])[i]-cluster_center)
43     cluster_cov = cluster_cov/np.sum(cluster_pt_weight)
44     return cluster_cov
45
46 def ShiftAxis(cluster_extension, cluster_orientation):
47     shift_index = np.zeros((3,3))
48     for axis in range(3):
49         for idx in range(3):
50             shift_index[axis, idx] = VectorAngle(cluster_orientation[idx], np.array(cluster_extension[axis]))
51     shift_index = linear_sum_assignment(shift_index, maximize=True)[1]
52
53     cluster_orientation = cluster_orientation[shift_index]
54     cluster_extension = cluster_extension[shift_index]

```

```

54     cluster_extension = cluster_extension[shift_idx]
55
56     for idx in range(3):
57         if np.dot(cluster_orientation[idx], np.identity(3)[idx]) < 0:
58             cluster_orientation[idx] = -cluster_orientation[idx]
59     return cluster_extension, cluster_orientation
60
61 def ClusterExtension(clusterlist, orientation=True):
62     cluster_pt_weight = Weight(clusterlist)
63     cluster_center = ClusterCenter(clusterlist)
64
65     if orientation:
66         cluster_cov = CalcCovariance(clusterlist, cluster_center, cluster_pt_
67         cluster_extension, cluster_orientation = np.linalg.eig(cluster_cov)
68         cluster_extension = np.sqrt(cluster_extension)*6
69         cluster_orientation = cluster_orientation.T
70         cluster_extension, cluster_orientation = ShiftAxis(cluster_extension,
71     else:
72         cluster_cov = CalcCovariance(clusterlist, cluster_center, cluster_pt_
73         cluster_extension = np.sqrt(cluster_cov)*6
74         cluster_orientation = np.identity(3)
75     return cluster_extension, cluster_orientation
76
77 # Load data and run analysis
78 with open('/content/drive/MyDrive/action/data/processed/mmr_action/data.pkl',
79     data = pickle.load(f)
80 train_data = data['train']
81
82 # Get window points
83 window_points = []
84 for i in range(5): # 5 frames window
85     points = train_data[i]['new_x']
86     window_points.append(points)
87 window_points = np.vstack(window_points)
88
89 # Perform clustering
90 dbscan = DBSCAN(eps=0.3, min_samples=6)
91 clustering = dbscan.fit(window_points)
92
93 # Check for valid clusters
94 cluster_mask = clustering.labels_ == 0
95 if np.any(cluster_mask):
96     clusterlist = pd.DataFrame(window_points[cluster_mask], columns=['x', 'y']
97
98     # With orientation
99     cluster_extension, cluster_orientation = ClusterExtension(clusterlist)
100     print('With orientation estimation:')
101     print('length:', cluster_extension[0])
102     print('width:', cluster_extension[1])
103     print('height:', cluster_extension[2])
104     print('orientation:', cluster_orientation[np.argmax(cluster_extension)])
105

```

```

106     # Without orientation
107     cluster_extension, cluster_orientation = ClusterExtension(clusterlist, or
108     print('\nWithout orientation estimation:')
109     print('length:', cluster_extension[0])
110     print('width:', cluster_extension[1])
111     print('height:', cluster_extension[2])
112     print('orientation:', cluster_orientation[np.argmax(cluster_extension)])
113 else:
114     print("No points in cluster 0")

```

➡ With orientation estimation:

```

length: 0.0
width: 0.0
height: 0.0
orientation: [1. 0. 0.]

```

Without orientation estimation:

```

length: 0.0
width: 0.0
height: 0.0
orientation: [1. 0. 0.]

```

```

1 import numpy as np
2 import pandas as pd
3 import matplotlib.pyplot as plt
4 from mpl_toolkits.mplot3d import Axes3D
5 from sklearn.cluster import DBSCAN
6 from sklearn.preprocessing import MinMaxScaler
7
8 def PlotSetting(ax):
9     ax.set_xlabel('X')
10    ax.set_ylabel('Y')
11    ax.set_zlabel('Z')
12    ax.set_box_aspect([1,1,1])
13
14 def GetColors(labels):
15     colors = ['tab:blue', 'tab:orange', 'tab:green', 'tab:red', 'tab:purple']
16     if isinstance(labels, np.ndarray):
17         return np.array(colors)[labels % len(colors)]
18     return colors[labels % len(colors)]
19
20 def PlotData(ax, points, color='tab:blue'):
21     ax.scatter(points[:,0], points[:,1], points[:,2], c=color, marker='.', a
22
23 def PlotEllipsoid(ax, center, orientation, color='dodgerblue', npoints=100):
24     u = np.linspace(0.0, 2.0 * np.pi, npoints)
25     v = np.linspace(0.0, np.pi, npoints)
26     x = np.outer(np.cos(u), np.sin(v))
27     y = np.outer(np.sin(u), np.sin(v))
28     z = np.outer(np.ones_like(u), np.cos(v))
29

```




```

30     for i in range(len(x)):
31         for j in range(len(x)):
32             x[i,j], y[i,j], z[i,j] = center + np.dot(orientation, [x[i,j], y
33
34     ax.plot_wireframe(x, y, z, rstride=10, cstride=10, color=color, alpha=0.
35
36 def PlotArrow(ax, center, orientation, extension=np.ones(3)/2):
37     ax.quiver(center[0], center[1], center[2],
38               orientation[0][0], orientation[0][1], orientation[0][2],
39               length=extension[0], color='tab:blue', normalize=True)
40     ax.quiver(center[0], center[1], center[2],
41               orientation[1][0], orientation[1][1], orientation[1][2],
42               length=extension[1], color='tab:orange', normalize=True)
43     ax.quiver(center[0], center[1], center[2],
44               orientation[2][0], orientation[2][1], orientation[2][2],
45               length=extension[2], color='tab:green', normalize=True)
46
47 def PlotClusterEllipsoid(ax, clusterlist, orientation=True, plot_arrow=True,
48     cluster_center = ClusterCenter(clusterlist)
49     cluster_extension, cluster_orientation = ClusterExtension(clusterlist, c
50     print('Center=', cluster_center, '\tL=', cluster_extension[0],
51           '\tW=', cluster_extension[1], '\tH=', cluster_extension[2],
52           '\tDirection=', cluster_orientation[np.argmax(cluster_extension)])
53
54     ax.scatter(cluster_center[0], cluster_center[1], cluster_center[2], colc
55     PlotEllipsoid(ax, cluster_center, (cluster_orientation * HorToVer(cluste
56
57     if plot_arrow:
58         PlotArrow(ax, cluster_center, cluster_orientation, cluster_extensior
59
60 # Perform clustering
61 scaler = MinMaxScaler()
62 scaled_points = scaler.fit_transform(window_points)
63 dbscan = DBSCAN(eps=0.1, min_samples=5)
64 clustering = dbscan.fit(scaled_points)
65
66 # Create visualization
67 fig = plt.figure(figsize=(10, 10))
68 ax = fig.add_subplot(111, projection='3d')
69 PlotSetting(ax)
70
71 cluster_mask = clustering.labels_ == 0
72 clusterlist = pd.DataFrame(window_points[cluster_mask], columns=['x', 'y', '
73 points = np.array(clusterlist)
74 labels = clustering.labels_[cluster_mask]
75
76 PlotData(ax, points, color=GetColors(labels))
77
78 unique_labels = np.unique(labels)
79 for label in unique_labels:
80     if label != -1:

```

```
81     mask = labels == label
82     cluster_points = pd.DataFrame(points[mask], columns=['x', 'y', 'z'])
83     PlotClusterEllipsoid(ax, cluster_points, orientation=False, plot_arr
84
85 plt.show()
```

↔ Center= [0. 0. 0.]      L= 0.0   W= 0.0   H= 0.0   Direction= [1. 0. 0.]



```

1 import numpy as np
2 import matplotlib.pyplot as plt
3 from mpl_toolkits.mplot3d import Axes3D
4
5 # Convert frames data to a single DataFrame for visualization
6 frames_data = []
7 for i in range(len(data['train'])):
8     frame_data = pd.DataFrame(data['train'][i]['new_x'], columns=['x', 'y',
9     frames_data.append(frame_data)
10 datalist = pd.concat(frames_data, ignore_index=True)
11
12 # Perform clustering
13 dbscan = DBSCAN(eps=0.4, min_samples=10)
14 clustering = dbscan.fit(np.array(datalist[['x', 'y', 'z']]))
15
16 # Create visualization
17 fig = plt.figure(figsize=(10, 10))
18 ax = fig.add_subplot(111, projection='3d')
19 PlotSetting(ax)
20
21 # Plot all points with cluster colors
22 points = np.array(datalist[['x', 'y', 'z']])
23 PlotData(ax, points, color=GetColors(clustering.labels_))
24
25 # Plot ellipsoids for each cluster
26 for i in range(np.max(np.unique(clustering.labels_))+1):
27     cluster_points = datalist[clustering.labels_==i]
28     PlotClusterEllipsoid(ax, cluster_points, orientation=True, plot_arrow=True)
29
30 # Plot noise points
31 PlotData(ax, points[clustering.labels_==-1], color='k')
32
33 plt.show()

```

## ✓ Cluster-based Observation state

Observation state of  $\text{frame\_num} = k$ ,  $\text{cluster\_num} = n$ :

$$z(k, n) = [\text{cluster\_center}, \text{cluster\_extension}, \text{cluster\_orientation}]$$

All info of  $\text{frame\_num} = k$ ,  $\text{cluster\_num} = n$ :

$$Z(k, n) = [z(k, n), z\_cov(k, n), \{\text{points\_index}\}]$$

```

1 import pandas as pd
2 import numpy as np
3 from sklearn.cluster import DBSCAN
4
5 def GenerateObservationStates(data_dict, startFrame, endFrame, orientation=1

```

```

6     observation_states = InitObservationDataFrame()
7
8     # Convert train data to DataFrame
9     frames_data = []
10    for i in range(len(data_dict['train'])):
11        frame_data = pd.DataFrame(data_dict['train'][i]['new_x'], columns=['
12        frame_data['frame_num'] = i
13        frames_data.append(frame_data)
14    data = pd.concat(frames_data, ignore_index=True)
15
16    for frame_num in range(startFrame, endFrame+1):
17        dbscan = DBSCAN(eps=0.4, min_samples=10)
18        datalist = data[(data.frame_num >= frame_num) & (data.frame_num < fr
19
20        clustering = ModelCluster(datalist, dbscan, sample_weight=True, show
21
22        for cluster_num in range(-1, np.max(np.unique(clustering.labels_))+1
23            clusterlist = datalist[clustering.labels_ == cluster_num]
24
25            observation_state = InitObservationDataFrame()
26            observation_state.at[0, 'frame_num'] = frame_num
27            observation_state.at[0, 'cluster_num'] = cluster_num
28            observation_state.at[0, 'track_num'] = cluster_num
29            observation_state.at[0, 'pts'] = list(clusterlist.index)
30
31            if cluster_num != -1:
32                cluster_center = ClusterCenter(clusterlist)
33                cluster_extension, cluster_orientation = ClusterExtension(cl
34                cluster_pt_weight = Weight(clusterlist)
35                cluster_cov = CalcCovariance(clusterlist, cluster_center, cl
36
37                observation_state.at[0, ['x','y','z']] = cluster_center
38                observation_state.at[0, ['l','w','h']] = cluster_extension
39                observation_state.at[0, ['ori_x','ori_y','ori_z']] = cluster
40                observation_state.at[0, 'cov'] = [cluster_cov]
41
42            observation_states = pd.concat([observation_states, observation_
43
44            print('Frame', frame_num, 'is done.')
45
46    return observation_states
47
48 # Example usage:
49 observation_states = GenerateObservationStates(data, 0, 10, orientation=True
50 print(observation_states)

```

```

➡ Frame 0 is done.
Frame 1 is done.
Frame 2 is done.
Frame 3 is done.
Frame 4 is done.
Frame 5 is done.
Frame 6 is done.
Frame 7 is done.
Frame 8 is done.
Frame 9 is done.
Frame 10 is done.

```

	frame_num	cluster_num	track_num	x	y	z	l	w	h	ori_x	ori_y
0	0	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
1	1	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
2	2	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
3	3	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
4	4	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
5	5	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
6	6	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
7	7	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
8	8	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
9	9	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN
10	10	-1	-1	NaN	NaN	NaN	NaN	NaN	NaN	NaN	NaN

	ori_z	cov	pts
0	NaN	NaN	[0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, ...
1	NaN	NaN	[110, 111, 112, 113, 114, 115, 116, 117, 118, ...
2	NaN	NaN	[220, 221, 222, 223, 224, 225, 226, 227, 228, ...
3	NaN	NaN	[330, 331, 332, 333, 334, 335, 336, 337, 338, ...
4	NaN	NaN	[440, 441, 442, 443, 444, 445, 446, 447, 448, ...
5	NaN	NaN	[550, 551, 552, 553, 554, 555, 556, 557, 558, ...
6	NaN	NaN	[660, 661, 662, 663, 664, 665, 666, 667, 668, ...
7	NaN	NaN	[770, 771, 772, 773, 774, 775, 776, 777, 778, ...
8	NaN	NaN	[880, 881, 882, 883, 884, 885, 886, 887, 888, ...
9	NaN	NaN	[990, 991, 992, 993, 994, 995, 996, 997, 998, ...
10	NaN	NaN	[1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, ...

## ✓ Track-based estimated state

Estimated state of  $\text{frame\_num} = k$ ,  $\text{track\_num} = t$ :

$s(k, t) = [\text{position}, \text{velocity}, \text{extension}, \text{orientation}]$

All info of  $\text{frame\_num} = k$ ,  $\text{track\_num} = t$ :  $S(k, t) = [s(k, t), s\_cov(k, t), Z(k, t)]$

Error covariance of  $s(k, t)$ :  $s\_cov(k, t) = P(k, t)$  in KF updates (later)

```

1 def InitEstimateDataFrame():
2     return pd.DataFrame(columns=['frame_num', 'track_num', 'x', 'y', 'z', 'vx', 'v

```